

eRoom Instructions

1. Turn Display (projector) ON




Please WAIT if a button is flashing, as device needs time to warm up

2. Turn on computer workstation or laptop

Laptop connection
Network/Data/Audio



PIC / AUDIO MUTE: Mutes the image or sound



3. Choose Source

VOLUME: Controls your audio levels

AUTO IMAGE: Syncs the projector to match computer's display settings

4. Please turn off projector when finished